

How to Transfer Allegro PCB Drawing to FloTHERM XT

Step 1 安裝 ODB++ Inside



- » Allegro 需安裝 ODB++ Inside 外掛程式
- 可自以下網站免費下載:

http://www.odb-sa.com/resources/odb-inside-for-cadence-allegro/#

ODB++ Inside for Cadence Allegro

ODB++ Inside generates NPI-ready ODB++ from Cadence Allegro®. ODB++ Inside includes a fully-integrated ODB++ Viewer for checking the data before delivery to NPI engineers in the manufacturing supply-chain.

ODB++ Inside Details

- Free-of-charge ODB++ output from Cadence Allegro versions 11 16.5
- Integral viewing of the ODB++ manufacturing-oriented product model
- Compatibility with all DFM, CAM and other ODB++ based manufacturing software tools in your supply chain, whether from Mentor (Valor Division), Frontline, or a wide range of 3rd-parties who support the format.

How to get it

- 1. Become a member of the ODB++ Alliance -> Click here to join.
- 2. If you are already a member, click here to sign-in or click on the version you would like to download on the right.
- 3. You will be asked to verify your contact information and provided a link to start your ODB++ Inside download.



Select, from the choices below, the version you wish to download:

Windows® XP SP2 & 3, Server 2008, Vista Business SP2 & Ultimate SP2, Windows 7 - (32 bit & 64 bit)


Windows® Server 2003 - (32 bit)

Red Hat Linux 4.4, 4.6, 5.1, 5.2, 5.3, 6 - (32 and 64 bit)

SUSE Enterprise 11 desktop and server editions - (32 and 64 bit)


Step 2 開啟 Allegro 模型檔






Step 3 Export ODB++ file








™ 工作目錄下將生成 odbjob_v7.tgz 檔案


Step 4 開啟 FloEDA.Bridge 程式 **(日本)**






匯入後結果





Step 5 轉入至 FloTHERM XT 《 一 一 二





總結



- ∞ 使用者必須先安裝 ODB++ Inside 的外掛程式至 Allegro
- ☞ FloTHERM XT v2.0 版本以上才支援 ODB++ 格式檔案匯入
- ≤>> 透過 ODB++ 格式檔案, FloTHERM XT 的 PCB 建模將更為方便

聯絡我們



₷ 易富迪科技有限公司

≤> 台北市松山區南京東路三段 305 號 5F

☎話:+886-2-87724131

№ 傳真: +886-2-27173122

≈ 網站: www.efd.com.tw

夠 客服信箱: CSD@efd.com.tw

