Summary

floview_64.exe

floview_64.exe has stopped working

A problem caused the program to stop working correctly.
Windows will close the program and notify you if a solution is
available.

[Debug] [Close program]

Detail

Most likely, this error is occurring because of the permission set to the FloTHERM solution directory folder. FloTHERM needs it to be set to allow full access. This error could occur if the model was recently saved or loaded into a new drive location which does not have full permission. Or if a new FloTHERM installation was done to a directory which does not have full permission. Reset the permission of the FloTHERM solution directory to have full control.

The default solution directory is here :C:\Program Files (x86) \ MentorMA \ flosuite_v122 \ flotherm \ flouser

If you have changed the path to the solution directory in FloTHERM, make sure to allow full access to the folder wherever that solution directory is.

In Windows the permissions can be changed by right clicking on the solution directory folder, click on Properties, select the Security tab and make sure to select full permission for that folder.

Permissions for Everyone	Allow
Full control	✓
Modify	✓
Read & execute	✓
List folder contents	✓
Read	✓
Write	✓

For special permissions or advanced settings, click Advanced.

[OK] [Cancel]

If you have forgotten where you set your solution directory and would like to reset the path settings, delete all the cfg files related to your user name as seen in the image below from the config directory located here C:\Program Files (x86) \ MentorMA \ flosuite_v122 \ flotherm \ config